



Blue Cat Graphics Ltd

Unit 13 - 5 Wakefield Street

Alicetown

Lower Hutt 5010

PO Box 13108

Johnsonville

Wellington 5440

www.bluecat.co.nz

Ph 04 499 7553 - Fax 04 499 7199

MAGNETIC CAR SIGN INSTRUCTION SHEET

Preparation before applying your magnetic sign

Make sure both the vehicle surface and the underside of the sign are clean, dry and waxed prior to application.

Applying your magnetic sign

Let one edge of the sign contact the vehicle in the desired position and let the magnetic power do the work as it puts the sign into place from the edge where you start to the edge opposite. If the sign is not where you want it, peel off and reposition the starting edge and repeat. Make sure that the entire surface of the sign is completely smooth against the vehicle with no air pockets underneath. In the winter the temperature of the sign should be 10C during installation but the temperature of the vehicle doesn't matter.

Maintenance of your magnetic sign

Remove the sign weekly and wipe dry both the magnet and the surface of the vehicle, this keeps moisture from collecting which can potentially damage a vehicle's surface. Cleaning the display side of your magnetic sign is just as easy, simply wash it with warm water and mild detergent.

Storing your magnetic sign

Avoid wrinkling by storing your magnetic sign flat, we do not recommend storing magnetic signs in a car especially on sunny days. Since your magnetic sign is permanently magnetic you need not protect against magnetic destruction. Do not put heavy objects on or against your sign in storage.

Last printed 11 March 2010